

Fermacell Installation Guide



- 1 The first row of Fermacell requires the 50mm lap joint to be cut off.
- 2 The cut edge should then be offered up against the perimeter insulation.
- 3 Dry lay all boards – two or three rows are recommended – before applying any adhesive.
- 4 It is highly recommended to mark the underlying pipe positions with a marker pen to avoid damage later when fastening boards together.
- 5 Apply Fermacell glue as per instructions on bottle.
- 6 Even small infill areas should include the 50mm lap joint.
- 7 Boards can be screwed together using the supplied screws. Note the boards are only screwed together and NOT down.
- 8 Alternatively, boards can be stapled with specific diverging staples.

FERMACELL SHOULD NOT BE INSTALLED IN TEMPERATURES LESS THAN +5°C