



Fermacell

Post installation guide

Once installed Fermacell requires 72 hours to become fully load bearing

DO's

The system can be used as working surface if the following precautions are observed.

Site traffic thoroughfares should be protected with 1 x 18mm ply. Sweep below ply!

The floor system can accept regular, normal site foot traffic after 24 hours at 20°C

Ladders to be used on 1 x 18mm ply after 24 hours

Towers and scaffolding to be erected on 1 x 18mm ply after 72 hours

Pallet trucks with load should be used only on 2 x 18mm ply after 72 hours

Excess glue to be scraped off after 24 hours

The heating system can be turned on after 72 hours – no heating protocol required

DO NOT's

Pallet trucks of ANY kind should NOT be used directly on the system

DO NOT apply heavy / point loads at the edge of the system

DO NOT allow scissor lifts, cherry pickers

DO NOT proceed with final floor installation on damaged areas

DO NOT allow any foot traffic on the system before the 24-hour cure time