

Screed Replacement Tile Installing final finishes



- 1 Installing linoleum / marmoleum/ carpet
- 2 In order to avoid 'shadowing' through the finished floor a levelling compound should be used over the Screed Replacement Tiles. In the case of carpets, gripper rods can be adhered to the Screed Replacement Tile system
- 3 Installing timber floors
- 4 Engineered timber floors can be adhered to the Screed Replacement Tiles using adhesive such as Sikabond T54. Localised levelling with smoothing compound may be required before installation of timber floor finishes.
- 5 Installing stone and tile floors
- 6 Stone and tile finishes should be adhered using quality adhesive conforming to BS EN12004 Class C2 /S1

SRT should be clear of grease and dust. Adhesive primers may be used if felt necessary by the stone installer.

Do NOT employ a decoupling mat.
- 7 Poured terrazzo floors

Installers install thin levelling compound
- 8 Marble fragments mixed with resin and poured directly over SRT system