



Dry levelling compound Installation Guide



- 1 Establish metre mark and required height of levelling compound
- 2 Distribute levelling compound to an average height in lines similar to the width of the levelling guides.
- 3 Level granules with smooth trowel
- 4 Place the parallel levels on the strips of granules to the appropriate height.
- 5 Fill in area between lines with further granules and then place the levelling rule on the parallel guides. Begin levelling by drawing back rule.
- 6 Add further levelling granules where required to build up height.
- 7 In larger rooms, installation is achieved by using further parallel guides.
- 8 Add more levelling granules as required using a smoothing trowel.
- 9 Insulation panels should be used to walk on the levelling compound. The granules will not compress when adopting this method.
- 10 The insulation panels can be laid directly on the levelling compound. Only walk on the panels already laid.